

## Multi-Unit Configuration Options

### BR PARALLEL CONFIGURATION

IMPORTANT: All units MUST have the same electrical configuration and temperature settings in a parallel configuration. Pipe lengths and dimensions are recommended to be identical for cold water inlet and hot water outlet connections to the units.



### BR SERIES CONFIGURATION

IMPORTANT: The first unit in the series should be set at a lower temperature setting than the second unit. The second unit should be set at the final desired output temperature. Pipe lengths and dimensions are recommended to be identical for cold water inlet and hot water outlet connections to the units.

